

# **Fairdinkum Concreters Skidz**

## **Users Guide to Fitting**

### **Hill Stop Hoodz - BRAKES**

#### **Innovation Patent No 2017101743**

#### **Never Worry About Sliding on a Slope Ever Again**



To fit Brake (Hill Stop Hoodz), Hold Flat against the Front or Rear of Skidz towards the outside edge as per photos above and push firmly into concrete until Brake is fully engaged.

Remove and Repeat as Required, depending on the Severity of the Slope 1 Brake maybe suffice allowing you more reach and coverage.

**W:** <https://www.concretersskidz.com.au>

**E:** [sales@concretersskidz.com.au](mailto:sales@concretersskidz.com.au)

**Ph:** 0418 464 457

**Find us on:**



"fairdinkum concreters Skidz"



"fairdinkum\_concreters\_skidz"